




New Corn Seeder Machine



Model	2BGFY-3	2BGFY-4
Rows	3 rows	4 rows
Crops	Corn, Soybean	
Row Spacing	55-70cm(adjustable)	
Seeding Depth	30-50mm	
Planting space(cm)	10-40cm (adjust the gears to change) (14cm/17cm/20cm/23cm/26cm/29cm/32cm/35cm) For corn, we recommend to adjust space to 23cm or26cm	
Shift gears	8 shift gears +8 adjustable planting space	
Corn seed size	<=13mm	
Driving method	gear driven,shaft driven	
Power required (HP)	18-30HP	30-40HP
Dimension of fertilizer box	150*40*30cm	200*40*30cm
Capacity of fertilizer box	180L	240L





1. Seeding transmission assembly
2. Gear transmission
3. Fertilizing transmission system
4. Soil-covering structure
5. Fertilizer ditcher
6. Main frame
7. Fertilizer box assembly
8. Square U-shape bolt
9. Seed box assembly
10. Shift gear box
11. Seed metering device assembly
12. Spring floating assembly
13. Earth wheel